

**“TO BE REMOVED FOR USE BY THE OCCUPANT.”**

Jason® Hydrotherapy  
8328 MacArthur Drive  
North Little Rock, AR 72118  
www.jasonhydrotherapy.com  
MADE IN THE U.S.A.



**JASON**  
HYDROTHERAPY  
AN AMERICAN INDUSTRIAL BRANDS® COMPANY

49-1010-604  
Date 05/2018

## OWNER'S MANUAL

# forma® and Designer MicroSilk® Baths INSTALLATION, OPERATION, AND MAINTENANCE



If the carton shows sign of damage, inspect the product before accepting and describe the problem on the Bill of Lading.

### INSPECTION

**Inspect the unit prior to installation. In the event of a problem, DO NOT install the unit.**

All components are factory assembled to the bath and the unit is water tested and inspected prior to leaving Jason Hydrotherapy.

If the carton shows sign of damage, inspect the product before accepting and describe the problem on the Bill of Lading.

**NOTE: Transportation and insurance from Jason's factory are the buyer's responsibility.**

**Damage sustained in transit is the responsibility of the carrier.** If damage is discovered, the carrier must be immediately notified in writing with a request for a representative to inspect the unit. Failure of the carrier to respond should be reported to the seller and carrier. Always file a freight claim promptly.

The installer is responsible for insuring that the unit is free from defects or shipping damage. **In the event of a problem, DO NOT install the unit.**

Jason® Hydrotherapy is not responsible for damage that might have been avoided by inspection or testing prior to installation.

Damage to the unit during installation will not be covered by warranty and is the responsibility of the installer.

### ALL WARRANTY CLAIMS ON ACRYLIC SURFACE DAMAGE MUST BE MADE PRIOR TO INSTALLATION.

Inspect plumbing and bath surface for missing or damaged components. Alert your dealer of any discrepancies.

To protect the unit from damage, keep the bath in the carton until ready for installation.

### EQUIPMENT ACCESS

In accordance with Building Codes, service access to all hydrotherapy bath equipment, controls and electrical connections must be provided during installation (**Recommended minimum 28" x 17" [71 x 43 cm]**). Insufficient access will hinder repair and maintenance. Warranty service will not cover costs of providing equipment access.

Jason® offers an optional removable lateral skirt for all rectangular baths. The skirts are available in matching acrylic colors and provide convenient access to bath equipment, as well as an excellent finished appearance.

The Specification Sheet for this bath contains additional technical information. This sheet can be provided by your dealer or accessed online at [www.jasonhydrotherapy.com](http://www.jasonhydrotherapy.com).

### OWNER'S RECORD

Dealer: \_\_\_\_\_

Date Purchased: \_\_\_\_\_

Date Installed: \_\_\_\_\_

Installer: \_\_\_\_\_

**PLACE SERIAL NUMBER CARD WITH  
PRODUCT CONFIGURATION IN THIS BOX**



# INSTALLATION INSTRUCTIONS

## INSTALLATION

See the **USER MAINTENANCE INSTRUCTIONS** section of this owner's manual, prior to Installation, for humidity and mold prevention suggestions.

1. **Finish Frame.** A finish frame under the shell rim should also always be constructed to support the bath deck and insure proper drainage toward the bath well. This frame is not intended to support the full bath weight (see Figures 1 & 2).

Jason offers a removable lateral skirt for most baths. The skirts are available in matching acrylic colors and provide convenient access to bath equipment as well as an excellent finished appearance. However, if Jason's lateral skirt is not used, an access panel **MUST** be provided to enable final electrical connections and service.

If a Jason lateral skirt is to be used, the bath deck must be leveled at 20.5" (52cm) from the support floor or the skirt will not fit properly.

**Allow ample clearance for the equipment.**

**CAUTION: Ambient temperature under the bath where equipment is installed must not exceed 122°F (50°C).**

2. 100% Silicone with mildew resistant properties should be applied between the water resistant backer board and the deck of the bath. **NOTE:** If you use a tile flange kit, modify the framing to support the bath lip as shown in **Figure 1**.
3. Install the drain and overflow assembly to the bath shell according to the instructions provided with the drain and position the bath in the area of intended installation.
4. Finish plumbing rough-in of drain and overflow

assembly. At this time, considerations should be made for the position and mounting of the faucet set, as well as all related plumbing.

5. **Remove the packing board before installing the bath.** The bath is equipped with separate bath equipment support bases which are joined for shipment with packing boards. Detach the packing board from the bath and from underneath the equipment.

**WARNING: Any modification to the equipment is not recommended and will void the Manufacturer's warranty.**

6. **Install the bath level for proper drainage.** Jason baths are designed to be supported at the base of the bath. If the floor is smooth and level, the baths' Level Form™ Base will provide proper drainage and support (See Figure 3).
7. Mortar is required when the sub floor is not smooth and level; when additional sound insulation is desired; or when the bath is installed in a drop-in application. In alcove installations, a bed of mortar may also be recommended to aid in leveling the bath. **NOTE:** Do not use a sand bed to install or level the bath.
8. **Secure the bottom of all equipment mounts so that it is level with the bottom of the bath.** Position the bath in the area of intended installation and cut the equipment support strap(s) to allow the equipment to rest firmly on the floor. We recommend securing the equipment mounts to the floor with removable fasteners for ease of servicing.
9. **Protect the acrylic bath surface from damage during installation with a suitable material, i.e., cardboard and/or plastic film.** The acrylic surface of this bath has been provided with a protective film which helps protect the bath during shipment and installation. Additional protection may also be required to protect the acrylic surface during installation. If the bath is tiled in, remove the necessary portion of the film when installing the tile.

Figure 1




Figure 2





Figure 3



**FIELD INSTALLATION OF THE MICROSILK® PUMP ASSEMBLY**

The Jason MicroSilk® system has been factory assembled following ETL and IAPMO guidelines. For shipping purposes on some bath models, the MicroSilk® Pump Assembly may be packaged separately and disconnected from the bath.

**NOTE:** These instructions can also be found in the Installation, Operation and Maintenance manual of the separately packaged MicroSilk hydrotherapy bath unit.

**WARNING:** System under pressure - Never perform maintenance while system is running.

**Note:** Verify the MicroSilk® Pump Assembly is the same unit that was provided for the bath being installed. The serial number listed on the label provided on the MicroSilk® Pump Assembly carton should match the serial number of the bath.

**Warning:** Any modification to the equipment is not recommended and will VOID the manufacturer's warranty.

To install the MicroSilk® Pump Assembly to the bath, the following procedures must be followed.

**Note:** Do not install the MicroSilk® Pump Assembly further than the length of the tubing that is factory installed on the bath. These tubing lengths have been designed for proper drainage of the system.

1. Position the bath in the area of intended installation.
2. Before beginning any work, the installer is to determine the proper location of the MicroSilk® Pump Assembly and service access.
3. Do not disconnect the plumbing lines that are secured to the bath with nylon tie straps (**Figure 5**).

Figure 4






Figure 5




4. Clamp the MicroSilk® Jet Line to the MicroSilk® Discharge Barb using the clamp provided on the tubing. Assure the MicroSilk® Jet Line will allow proper drainage to the Jets (**Figure 6**). The discharge hose must have a continuous drop from the discharge barb to the jet fitting.

Figure 6



5. Clamp the MicroSilk® Suction Line to the MicroSilk® Suction Barb using the clamp provided on the tubing. Assure the MicroSilk® Suction Line will allow proper drainage to the suction (**Figure 7**). The suction hose must have a continuous drop from the suction barb to the suction fitting.

Figure 7



6. Clamp the MicroSilk® Drain Line to the MicroSilk® Drain Barb using the clamp provided on the tubing. Assure the MicroSilk® Drain Line will allow proper drainage to the drain fitting (**Figure 7**). The drain hose must have a continuous drop from the drain barb to the drain fitting.

**Caution: Confirm all tubing is fully engaged on its respective barb and its clamp has secured the tubing to the barb.**

7. The bottom of the Pump Mount must be secured and level with the bottom of the bath, it is recommended removable fasteners be used in case any future servicing is required.
8. Continue bath installation per the Jason Owner's Manual Installation, Operation, and Maintenance guide.

## ELECTRICAL

**Electrical Power Supply:** These instructions are written assuming 60Hz, 120v power supply. Special notations are also included for export versions of the equipment and power supply.

**WARNING: Verification of electrical requirements MUST be made before installation. Refer to the equipment labels for voltage and frequency requirements.**

**NOTE:** The bath is designed for indoor use only. The electrical equipment must not be exposed to direct or indirect water or moisture contact. The electrical equipment must also be protected from dust and other airborne debris before, during, and after installation.

1. **Electrical Service:** A licensed electrician must provide the "dedicated" electrical service protected by a GFCI. The location of the GFCI must be at least five (5) feet (152cm) away from the inside surface of the bath, accessible for regular testing. Use copper conductors only.

**DANGER — RISK OF ELECTRIC SHOCK:** Connect only to a circuit protected by a Ground Fault Circuit Interrupter (GFCI). In the unlikely occurrence of a current imbalance in the power conductors, the GFCI will interrupt the power to the bath.

**WARNING:** The electrical service to the GFCI must not be interrupted by any control device. Likewise, the electrical service from the GFCI to the bath control should be direct and not interrupted by a switch. Never use a switch in conjunction with a control device. **This will VOID THE MANUFACTURER'S WARRANTY.**

2. **GROUNDING IS REQUIRED**

**The unit should be installed by a qualified service representative and properly grounded.**

3. **INSTALL SERVICE CONNECTION AT LEAST 6" (15cm) ABOVE SUB FLOOR.**

**ALL LOCAL AND STATE ELECTRICAL AND PLUMBING CODES MUST BE OBSERVED.** Where there are no local codes, the **National Electric Code (NEC)** and **Uniform Plumbing Code (UPC)** shall be observed. It is the responsibility of the installer/owner to determine specific code compliance prior to installation of the product.

**NOTE:** In the Commonwealth of Massachusetts, installation is to be done by a Massachusetts licensed plumber.

4. **120V Electrical Service- MicroSilk® Control Box.**  
The MicroSilk® generator unit may be shipped separate from the bath. Follow the instructions for the **MicroSilk® Pump Assembly Field Installation** in the **Installation** section of this owner's manual (instructions are also packaged with the MicroSilk® unit packaging). The control box has a 36" (91cm) cord with plug end. The MicroSilk® control box is mounted on a stand that is temporarily secured to the packing board for shipping. During installation, the control box bracket and controls must be positioned horizontally and located to permit access for inspection and servicing. If the MicroSilk® generator unit is shipped separate from the bath, the MicroSilk® pump's power cord will need to be plugged into the control box. Connect the pump's male NEMA plug to the female NEMA plug of the control box's load line. The MicroSilk control must be plugged into a dedicated 120V, 20A, 60Hz, GFCI protected circuit **(See Figure 8).**
5. **240V Electrical Service- MicroSilk® Control Box (Export).**  
The MicroSilk® generator unit may be shipped separate from the bath. Follow the instructions for the **MicroSilk® Pump Assembly Field Installation** in the **Installation** section of this owner's manual (instructions are also packaged with the MicroSilk® unit packaging). The control box has a 36" (91cm) cord with a junction box connection. The MicroSilk® control box is mounted on a stand that is temporarily secured to the packing board for shipping. During installation, the control box bracket and controls must be positioned horizontally and located to permit access for inspection and servicing. If the MicroSilk® generator unit is shipped separate from the bath, the MicroSilk® pump's power cord will need to be plugged into the control box. Connect the pump's male J+J plug to the female J+J plug of the control box's load line. The MicroSilk® control must be plugged into a dedicated 240V, vffgdg 20A, 50 or 60 Hz, GFCI protected circuit **(See Figure 8).**

**DANGER: Do not alter the factory installed wiring. All building materials and wiring should be routed away from the equipment or other heat-producing components of the unit.**


Figure 8



**Standard / Premier Edition**



**Signature Edition**



## CLEANING

1. **Remove all loose debris.** Construction plaster or excess grout can be removed with the use of a wood (edge) trowel.
2. **Paint or tar stains** may need to be removed with a cleaner such as paint thinner, turpentine, or isopropyl alcohol (rubbing alcohol). Never allow the cleaner to soak against the acrylic surface for long periods of time. **Always rinse the surface immediately following the use of cleaners.**
3. Follow the manufacturer's instructions for safe use of cleaning products. If the surface becomes scratched or dulled, it may be restored by using a quality plastic polish, like Novus Plastic Polish No. 2 (available from the Jason Dealer). **It is always preferable to protect the acrylic surface during installation to minimize cleanup and prevent surface damage.**

## WATER TESTING

Before finishing the installation, it is recommended that the bath be water tested and the plumbing tested for leaks.

1. **Before water-testing the bath,** make sure any pump unions are hand tight. Do not over tighten or use a pipe wrench. This will damage the unions and cause leaking. If the unit leaks with the unions hand tight, then loosen the unions(s) and check the O-ring seal to ensure it is properly seated.
2. **Fill and operate the bath.** Close the drain and fill the bath with water to at least 10 inches [25 cm] below the bath deck. The inlet temperature should not exceed 40°C (104°F). Refer to the FILLING AND DRAINING section of this owner's manual for more information.

### **NEVER RUN THE PUMP WITHOUT ENOUGH WATER IN THE BATH TO COVER THE JETS.**

3. **Inspect the plumbing for leaks.**
4. **Turn the equipment Off and then drain the water.** The bath unit and its plumbing are designed to drain after each use whether used as a hydrotherapy bath, soaking bath, or when taking a shower.

# MICROSILK® CONTROL BOX CONNECTIONS

## STANDARD EDITION MICROSILK®

Jason's Standard Edition MicroSilk® system features the best in luxury bathing for the leisure bath industry. To assure that your bath functions properly, the MicroSilk® pump control box must be properly connected.


**NOTE: For 120V systems, the power cord for the MicroSilk® control box must be plugged into a 120V, 20 amp GFCI dedicated circuit.**

## The MicroSilk® Control Box

The MicroSilk® unit and keypad must be plugged into the proper receptacles for correct operation of the MicroSilk® system. See **Figure 9** for connections:

- (A) The power cord for the MicroSilk® control box must be connected into the proper GFCI dedicated circuit for the system (see note).
- (B) The MicroSilk® pump's power cord will need to be plugged into the control box. Refer to the **ELECTRICAL** section of this manual for connecting the pump to the control box.
- (C) Eight-pin mini-DIN terminal for the MicroSilk® Keypad.

Figure 9



**Notes:**

A Single Dedicated 120V/60Hz 20A GFCI Protected Service is required for all bath equipment.

Additional options may require multiple outlets installed on the single service.

**NOTE:** This diagram also applies to 50 Hz, 240V pumps, controls, and power supply systems. Except that the MicroSilk® Pump junction boxes must be connected into one dedicated 240V, 20 amp GFCI circuit.



**PREMIER EDITION MICROSILK®**

Jason's Premier Edition MicroSilk® system incorporates all the features of the Standard Edition system and includes the benefits of an ozone sanitation system and an LED Chromotherapy light kit. To assure that your bath functions properly, the MicroSilk® control box must be properly connected.




**NOTE: For 120V systems, the power cord for the MicroSilk® control box must be plugged into a 120V, 20 amp GFCI dedicated circuit.**

**The MicroSilk® Control Box**

The MicroSilk® unit, keypad, LED light, and Ozone Sanitation Unit must be plugged into the proper receptacles for correct operation of the MicroSilk® system. See **Figure 10** for connections:

- (A) The power cord for the MicroSilk® control box must be connected into the proper GFCI dedicated circuit for the system (see note above).
- (B) The MicroSilk® pump's power cord should be plugged into the female cord connection on the ozone unit, prewired to the control box.
- (C) Eight-pin mini-DIN terminal for the MicroSilk® Keypad.
- (D) Six-pin mini-DIN terminal for LED light.

Figure 10



Notes:  
 A Single Dedicated 120V/60Hz 20A GFCI Protected Service is required for all bath equipment.  
 Additional options may require multiple outlets installed on the single service.

**NOTE:** This diagram also applies to 50 Hz, 240V pumps, controls, and power supply systems. Except that the MicroSilk® Pump junction boxes must be connected into one dedicated 240V, 20 amp GFCI circuit.

## SIGNATURE EDITION MICROSILK®

Jason's Signature Edition MicroSilk® system is the most advanced bath manufactured by Jason Hydrotherapy and features the ultimate in luxury bathing for the leisure bath industry. The MicroSilk® control box must be properly connected for the bath to function correctly.


**NOTE: For 120V systems, the power cord for the MicroSilk® control box must be plugged into a 120V, 20 amp GFCI dedicated circuit.**

### The MicroSilk® Control Box

The MicroSilk® unit, keypad, LED light, Ozone Sanitation Unit and Water Level/Temperature Sensor must be plugged into the proper receptacles for correct operation of the MicroSilk® system. See **Figure 11** for connections:

- (A) The power cord for the MicroSilk® control box must be connected into the proper GFCI dedicated circuit for the system (see note).
- (B) The MicroSilk® pump's power cord should be plugged into the female cord connection on the ozone unit, prewired to the control box.
- (C) Eight-pin mini-DIN terminal for the MicroSilk® Keypad.
- (D) Six-pin mini-DIN terminal for LED light.
- (E) Six-pin mini-DIN terminal for installation of the water sensor to the MicroSilk® control box.

Figure 11



Notes:  
 A Single Dedicated 120V/60Hz 20A GFCI Protected Service is required for all bath equipment.  
 Additional options may require multiple outlets installed on the single service.

**NOTE:** This diagram also applies to 50 Hz, 240V pumps, controls, and power supply systems. Except that the MicroSilk® Pump junction boxes must be connected into one dedicated 240V, 20 amp GFCI circuit.

# OPERATING INSTRUCTION, FEATURES, AND CONTROLS

---

## INTRODUCTION

This manual contains all of the information needed for the proper installation and operation of your Jason MicroSilk® bath. The bath has been designed to give you years of relaxing trouble-free service, provided the unit is maintained and operated in accordance with these instructions.

Thoroughly clean and disinfect the unit as described in the **CLEANING** section of the **USER MAINTENANCE INSTRUCTIONS** section of this owner's manual before its first use and periodically thereafter.

**CAUTION:** Keep hair, towels, and clothing away from the suction fitting whenever the equipment is On. Never operate the equipment with the suction cover off, as doing so voids the manufacturer's warranty. It is a safety cover designed to eliminate the potential of hair and body entrapment.

All Jason MicroSilk baths are pre-plumbed at the factory.

**WARNING:** Before operating, refer to the instructions at the end of this owner's manual pertaining to the risk of fire, electric shock, or injury to persons.

## FEATURES AND CONTROLS

### STANDARD AND PREMIER EDITION MICROSILK®

The Jason Standard Edition MicroSilk® bath includes a Microbubble generator unit, an electronic control, and a 20-minute timer.

The Jason Premier Edition MicroSilk® bath provides all the features of the Standard Edition with the included benefits of an LED Chromatherapy Mood Light, and an Ozone Sanitation system.

### Standard/Premier Touchpad

One main control touchpad mounted on the bath deck features several icons used by the bather to control the MicroSilk® unit and LED mood light. A built-in timer shuts the pump off 20 minutes after being activated.

### SIGNATURE EDITION MICROSILK®

The Jason Signature Edition MicroSilk bath includes a Microbubble generator unit; Chromatherapy mood light, Automatic Ozone System that will be operated any time the pump is powered; a digital control with LCD-display window; low water and temperature sensors; and a 20-minute timer.

### Signature Touchpad

A main control touchpad mounted on the bath deck features an LCD readout which alternately indicates the water temperature (+/- 5° F) and time remaining. The Signature Edition touchpad allows the bather to control the MicroSilk® pump and LED mood light. A built-in timer shuts off the pump 20 minutes after being activated.

### Signature Remote Control

In addition to the main control touchpad installed on the bath deck, a floating, waterproof Universal Remote Control is provided with all Signature Edition MicroSilk® baths. This remote control provides the same control functions as the bath's main control console, plus the bather may remotely operate a TV, DVD, VCR, CD, etc. Refer to the Instruction Manual provided with the remote control for detailed instructions.

### MicroSilk® Port

A strategically placed MicroSilk® port is provided for complete enjoyment of your bath.

### MicroSilk® Unit

The MicroSilk® unit generates oxygen-rich microbubbles that fill the bath. MicroSilk® units provided on Jason baths are factory tested when assembled and again retested after installation on the bath.


### Filling and Draining

Close the drain and fill the bath with water at least two (2) inches (50mm) above the jets. The inlet temperature should not exceed 40° C (104° F). When bath is in use, turn the unit Off before draining the water. The bath unit and its plumbing are designed to drain after each use whether used as a hydrotherapy bath, soaking bath, or just taking a shower.

**NOTE:** If the unit fails to operate, check the breaker panel to ensure that the circuit breaker is on. Check the GFCI by testing and resetting it. Also check the water level in the bath; it must be above the MicroSilk® port for the pump to operate. If the unit still fails to operate, refer to the Trouble Shooting Guide section of this manual. If the unit still fails to operate and is out of warranty, contact an authorized service technician for repair. If the unit is within the warranty period, contact JASON Technical Services at 800-255-5766. DO NOT ATTEMPT TO RESOLVE THE PROBLEM.

## STANDARD AND PREMIER EDITION MICROSILK® TOUCHPAD

Figure 12



### OPERATING INSTRUCTIONS

#### MicroSilk® On/Off Icon

The MicroSilk® icon is used to activate the MicroSilk® unit and the 20-minute timer.

- Press the icon the first time to start the MicroSilk® unit.
- Press the icon again to shut off the MicroSilk® unit.

#### LED Light Icon


The LED Light icon is used to operate an LED light (if installed).

- Press the icon for less than two (2) seconds to turn the lights Off or On.
- Hold the icon for more than two (2) seconds to change modes.

This function has a two-(2) hour timer and remembers the last mode.

## SIGNATURE EDITION MICROSILK® TOUCHPAD

Figure 13



### OPERATING INSTRUCTIONS

#### MicroSilk® On/Off Icon

To control the operation of the MicroSilk® unit, press and release for each setting: ON or OFF. A 20-minute decreasing timer will be initiated when the pump motor starts. Press and hold the MicroSilk® icon to cycle through each pump setting. The MicroSilk® icon lights when the water is at operating level and the LCD displays "System Ready". The LCD will display "MS On", or "MS Off" when the key is pressed. It also toggles between Temperature and Timer at 5 second intervals. "Low Water" is displayed for 5 seconds if no water is detected.

#### LED Light Icon

Hold the key for less than two (2) seconds to turn the lights Off or On. Hold the key for more than two (2) seconds to change modes. The Light icon should remain lit as long as the bath is connected to a power supply. This function has a two-hour timer and remembers the last mode. The LCD displays "Light On" or "Light Off" while the key is pressed for less than two (2) seconds, "Light Cycle" is displayed if pressed for more than two (2) seconds.

#### Customized Settings

The 12-character LCD display can be customized by pressing the two Diagnostic Function icons simultaneously for five (5) seconds, while the system is off. **Note:** Use the above figure to locate the icons. A menu will be displayed to choose the following: Product Test Diagnostics, Temperature (°F or °C) and Language (English or Spanish).

#### Menu Instructions

Use the top Diagnostic Function icon to scroll through the different menu items. Use the bottom Diagnostic Function icon to change an option. For example, press and release the top icon to change from Product Test to the Temperature option. Press and release the bottom icon to change the temperature display from °F (Fahrenheit) to °C (Celsius).

#### Product Test Diagnostics

After selecting the Product Test option from the menu, the unit will perform a series of tests to confirm correct installation of components. The test will begin by displaying the configuration number, followed by the software revision number. Next, the display will then test the Temperature and Low Water level sensor (ITW-209). Next, each of the six (6) icon buttons will begin to light. Press the illuminated button to proceed to the next icon. After the icon test, the LED Light unit will be tested. If you receive an error on any of the tests, confirm proper installation of component to the correct control box. (See the **CONTROL BOX CONNECTIONS** section).

#### Remote Control

The Signature Edition control system includes a waterproof floating Universal Remote Control. It controls all bath functions plus a TV, DVD, CD, etc., which can be heard through the Sound Immersion Transducers (optional).

# USER MAINTENANCE INSTRUCTIONS

---

## HUMIDITY

**WARNING: Avoid high humidity levels in your home. Mold, mildew, fungi and bacteria which may be harmful to health thrive in areas with continued high humidity levels; therefore, every precaution should be taken to make sure your plumbing fixtures, including bathtubs, hydrotherapy baths, or showers do not become a source of high humidity due to improper installations or leaks.**

To avoid having your plumbing fixtures become a source of unwanted humidity, please make sure the following steps are taken prior to installation.

1. Make sure the area where the bathtub or shower is installed is well vented and allows enough ventilation and air circulation to dry the bathroom environment within a short time after taking a bath or shower.
2. If your bath or shower unit is tiled-in, use units with an integral tile flange or make sure a tile flange kit or a similar mechanical barrier is installed to prevent shower spray, splash, or overflow to leak behind the bathtub.
3. Make sure the plumber properly tests your hydrotherapy bath before it is roughed in to make sure there are no leaks and it is installed with proper access to bath equipment.
4. Make sure that all the plumbing and fixtures in the bathroom are in good working order and have no leaks.
5. Do not use carpeting or other materials or furniture, which can hold moisture in your bathroom.
6. Use disinfectant to clean any bathroom surfaces which are regularly exposed to moisture.
7. Clean and disinfect humidifier and dehumidifiers as recommended by the manufacturer. Replace the air filter on the HVAC unit once a month.
8. Clean moldy surfaces as soon as any mold appears by using a detergent/soapy solution and appropriate household cleaner. Always use gloves during cleaning. Dispose of any sponges or rags used to clean mold.

## CLEANING

With minimum care, your acrylic-surfaced bath will retain its high-luster finish for many years. For regular cleaning use Jason Bath Cleaner or a mild **NONABRASIVE** liquid detergent solution (i.e. glass cleaner) and a soft, wet cloth or sponge. Do not run the hydrotherapy system with foaming cleaners or soaps. Rinse the bath thoroughly after cleaning.

## SURFACE MAINTENANCE

Areas with minor scratches or dull surfaces can be restored by applying commercially available plastic polish (i.e. Novus Plastic Polish No. 2, available at your Jason dealer), followed by an application of acrylic paste wax. Buff the surface with a clean, soft cloth. Do not use sandpaper, steel wool, or abrasive rubbing compounds.

If scratches are too deep to rub out, or if the damage penetrates the acrylic surface, consult your dealer for recommendations on surface repair.

## FLUSHING / SANITIZING

Upon start-up and not to exceed 90 days, your bath and plumbing system should be flushed. To do so, close the drain and fill the bath with warm water to at least two (2) inches [5.1 cm] above the highest jet. Pour in Jason Bath System Cleaner and follow the directions on the bottle. **DO NOT** use bleach or other chlorinated cleansers directly on the metal trim.

## REPAIR

Refer all plumbing or electrical repair to a qualified service technician. **DO NOT ATTEMPT TO RESOLVE THE PROBLEM.** This can result in danger of electrical shock or damage to the unit and will **VOID THE WARRANTY.** Remember, when contacting your dealer or service representative; always have your serial number, proof of purchase, and model number. This will ensure a quick response on warranty items. The serial number can be found on the front page of this manual or on the small card adhered to the back of the bath just above the equipment.

**ALL WARRANTY REPAIRS MUST BE AUTHORIZED BY THE MANUFACTURER BEFORE WORK IS STARTED.**

# TROUBLE SHOOTING GUIDE

If you believe the unit to be within the warranty period, you must contact **Jason Customer Service: 1-800-255-5766** with the bath's Product and Serial numbers before work is started.

**ALL WARRANTY REPAIRS MUST BE AUTHORIZED BY JASON BEFORE WORK IS STARTED.**

FOR SERVICE, ALWAYS CONTACT YOUR DEALER OR AUTHORIZED SERVICE CENTER

**WARNING: Always turn off power at the main electrical service panel when servicing the bath.**

MICROSILK® PUMP SYSTEM		
SYMPTOMS	POSSIBLE CAUSES	RECOMMENDED ACTION
MicroSilk system fails to operate.	<ul style="list-style-type: none"> <li>a) No power to the MicroSilk unit.</li> <li>b) Motor is not plugged in.</li> </ul>	<ul style="list-style-type: none"> <li>a) Reset circuit breakers and GFCI if tripped. Check fuses and replace if bad.</li> <li>Check voltage at motor when control is on. If no voltage, the control is defective. If voltage is present, motor is defective.</li> <li>b) Make sure plug is fully inserted into the outlet.</li> </ul>
Pump operates, but no Micro-bubbles are injected into water.	<ul style="list-style-type: none"> <li>a) Venturi clogged.</li> <li>b) Float valve not operating</li> </ul>	<ul style="list-style-type: none"> <li>a) Refer to installer/dealer.</li> <li>b) Refer to installer/dealer.</li> </ul>
Pump operates, but water is not being pumped.	<ul style="list-style-type: none"> <li>a) Suction or discharge blocked.</li> <li>b) Suction air leak. (System usually surges.)</li> </ul>	<ul style="list-style-type: none"> <li>a) Remove obstruction.</li> <li>b) Make sure connection is tight on suction side of the pump.</li> </ul>
Pump does not manually shut off.	<ul style="list-style-type: none"> <li>a) Digital or Touch Control defective.</li> </ul>	<ul style="list-style-type: none"> <li>a) Refer to installer / dealer.</li> </ul>
Pump shuts off by itself, or before set time elapses.	<ul style="list-style-type: none"> <li>a) Pump motor overheated and thermal protection device deactivated motor. (Possibly low voltage.)</li> <li>b) GFCI tripped.</li> <li>c) Water level fell below recommended level. (Digital Control)</li> </ul>	<ul style="list-style-type: none"> <li>a) Make sure motor air cooling vents are not blocked, clear and allow motor to cool down. (Check service &amp; wire size.)</li> <li>b) Refer to Jason Customer Service.</li> <li>c) Fill to recommended level. (4" above jet)</li> </ul>
Pump does not turn off after set time elapses.	<ul style="list-style-type: none"> <li>a) Wiring error or control problem.</li> </ul>	<ul style="list-style-type: none"> <li>a) Refer to installer / dealer.</li> </ul>
Pump will not turn off when water is drained from the bath.	<ul style="list-style-type: none"> <li>a) Water level sensor defective.</li> </ul>	<ul style="list-style-type: none"> <li>a) Refer to installer / dealer</li> </ul>
Pump leaks at shaft.	<ul style="list-style-type: none"> <li>a) Damaged or defective shaft seal.</li> </ul>	<ul style="list-style-type: none"> <li>a) Refer to installer / dealer.</li> </ul>
LED Light will not operate	<ul style="list-style-type: none"> <li>a) LED light is loose in the socket.</li> <li>b) LED cable disconnected.</li> </ul>	<ul style="list-style-type: none"> <li>a) Access LED light and assure that it is properly installed in the socket</li> <li>b) Verify correct cable connections.</li> </ul>

**WARRANTY REGISTRATION: Register your product's warranty online at [www.jasonhydrotherapy.com](http://www.jasonhydrotherapy.com).**

## WARRANTY

Jason® Hydrotherapy (Jason), warrants its baths to be free from defects in workmanship and materials as provided in the enclosed Warranty Statement and Warranty validation card.

The pre-addressed warranty registration card **MUST** be filled out by the purchaser within thirty (30) days from purchase and mailed to Jason Hydrotherapy, in order for limited warranty to become effective.

# IMPORTANT SAFETY INSTRUCTIONS

## INSTRUCTIONS PERTAINING TO THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS.

This manual contains information and instructions for proper operation and maintenance of your hydrotherapy bath. Failure to follow these instructions could result in personal injury, electrical shock, or fire.

**WARNING:** When using this unit, basic precautions should always be followed, including the following:

## READ AND FOLLOW ALL INSTRUCTIONS CAREFULLY

### DANGER: TO REDUCE THE RISK OF INJURY, FOLLOW THESE PRECAUTIONS:

- A. Do not permit children to use this product unless they are closely supervised at all times.
- B. Use this unit only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- C. The water in a hydrotherapy bath should never exceed 40°C (104°F). Water temperatures between 38°C (100°F) and 40°C (104°F) are considered safe for a healthy adult. Use time should be limited to approximately 30 minutes, followed by a shower to cool down. Longer exposures may result in hyperthermia. The symptoms of this condition are nausea, dizziness and fainting, and it can be fatal. Lower water temperatures are recommended for extended use (exceeding 10 -15 minutes) and for young children.
- D. Since excessive water temperatures have a high potential for causing fetal damage during the early months of pregnancy, pregnant or possibly pregnant women should limit hydrotherapy bath water temperatures to 38°C (100°F).
- E. The use of drugs or alcoholic beverages before or during hydrotherapy bath use may lead to unconsciousness with the possibility of drowning. Never use the hydrotherapy bath while under the influence of alcohol, anticoagulants, stimulants, antihistamines, vasoconstrictors, vasodilators, hypnotics, narcotics, or tranquilizers.
- F. Persons with a medical history of heart disease, low or high blood pressure, circulatory system problems, or diabetes should consult a physician before using a hydrotherapy bath.
- G. Persons using medication should consult a physician before using a hydrotherapy bath since some medication may induce drowsiness while other medication may affect heart rate, blood pressure, and circulation.

**DANGER:** To reduce the risk of injury, enter and exit the bath slowly. Do not operate this unit unless the suction cover is attached over the suction inlet fitting and the jet assemblies are installed. There should be at least two (2) inches of water above the highest jet location during hydrotherapy bath operation. **NEVER RUN UNIT DRY.**

**WARNING:** Never operate electrically connected devices in or near the bath. Never drop or insert any object into any opening.

This unit must be connected to a supply circuit that is protected by a GFCI. Such a device should be installed by a licensed electrician and should be tested on a regular basis (at least monthly). To test the GFCI push the **TEST** button. The GFCI should interrupt the power. Push the **RESET** button and the power should be restored. If the GFCI fails to operate in this manner, there is the possibility of an electric shock. **DO NOT USE.** Disconnect the unit and have the problem corrected by a qualified service technician.

To avoid the possibility of personal injury and discoloration of the acrylic surface, the inlet water temperature should not exceed 40°C (104°F). The bath should be drained after each use. Each bather should start their bath with fresh water. Do not use oil-based additives in your hydrotherapy bath.

**CAUTION:** Do not use harsh abrasives or solvents for cleaning this unit.

**INSTALLER/OWNER BEARS ALL RESPONSIBILITY TO COMPLY WITH ALL STATE AND LOCAL CODES WHEN INSTALLING THIS PRODUCT.**

## SAVE THESE INSTRUCTIONS

---

### JASON HYDROTHERAPY

8328 MacArthur Drive • North Little Rock • Arkansas • 72118-2029

[www.jasonhydrotherapy.com](http://www.jasonhydrotherapy.com)