



OWNER'S MANUAL

AH100 Grip Handle Kit INSTALLATION INSTRUCTIONS

INTRODUCTION

Included with each AH100 Grip Handle Kit:

- One (1) AH100 Grip Handle
- Two (2) 1- 1/4" Washers
- Two (2) 5/16" x 3/4" Hex Head Bolts

INSPECTION

Inspect the kit for damage and any shortages prior to installation. Damage sustained in transit is the responsibility of the carrier. If transit damage is discovered, notify the carrier immediately and file a freight claim with them. If any shortages are noted, contact Jason Customer Service at 800-255-5766.

TOOLS & MATERIALS REQUIRED

For ease of installation, and safety, Jason recommends the use of the following tools: level, square, 1/2" wrench (or an adjustable wrench), drill, silicone sealant, and 1/8" & 3/8" drill bits.

INSTALLATION

1. To obtain the hole-layout and proper handle placement, first locate the desired position of the AH100 Grip Handle on the Bath Deck.

NOTE: The AH100 Grip Handle Kit Must be Installed before bath installation.

2. Following **Figure 1**, mark the Lower Hole's position 5" [12.4cm] down from the Bath Deck. Verify the handle is positioned flush to the bath deck and mark the Upper Hole's position. See **Figure 2**.
3. Drill two initial 1/8" [3.5mm] pilot holes at the locations marked in the previous step.

NOTE: To avoid chipping or cracking the acrylic surface, **DO NOT** drill the pilot hole completely through the bath.

Using the drilled pilot hole as a guide, finish drilling the holes with a 3/8" [10mm] diameter drill bit.

4. Place the handle on the bath, being sure to align the handle with both holes, and hand tighten each of the bolts and washers on.
5. Using a 1/2" wrench, fully tighten each of the bolts until the handle is secure.
6. Apply silicone sealant to the bolts on the back of the bath.

