

Device Code List For VT3630B

A U X

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD	
ABC			008,017,018 019,023,032 040,049,130 140			
Acre					135	
Acoustic Research				044		
ADC				045,046		
ADCOM				038		
Addsion	081					
Admiral	063,136,177,180 206,207	066				
Adventura	160	038				
Aelanta			089			
AEON			055			
Aiko	103					
Aiwa	006,007,008	032,034,035,036 038,107,108,120		050,069,109	146	
Akai	113,114,164,181 190	033,057,084,100 111,112,113,114 115,143		016,139	150	
Akiba		119				
Alfa Gold			185			
Alleron	136					
Amark	178,179,202					
Ambassador	098					
American High		045,072				
Amstrad	030,098	107,038				
Amusewell				116		
Anam	068,083,148,177 253					
Anitech		119				
Anvision			022,042,046			
AOC	005,014,029,048 100,113,136,152 176,177,188,190 200,202,204,214					
APO			067			
Apex					147	
Archer	202		069			
ASA		045,047				
Asha		103				
ASIA Giant			054,064,166			
Asuka		047				

**Device Code List For VT3630B**

**A U X**

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD
ATLE				052	
Audio Dynamics		025,109,113,142			
Audiovox	177,202	047,109			
AWA	040,082,193,266				
Baird		019,038			
Basic Line		119			
Beaumarck		103			
BESTLINK			051,091		
Beicor	100,114				
Bell & Howell	063,136,177,195	019,020,066			
BENJAMIN			151		
Blaupunkt		006,083			
Blue Star	054				
BPL	054,218,256,257 258				
Bradford	177				
Brockwood	100				
Broksonic	177,202,234	055,056,110,112			
Bush		119			
Cabestar			022,042,046		
California Audio Lab				003	
Calix		047			
Canon		072,137			
Candle/ Citizen	086,103,113,114 132,148,160,171 176,178,188,209	038,046,047,072 103,109,138,139 141	048		
Capehart		139			
Caraveil				077(VCD)	
Carver	037,060	045,144		069	
CASIO				138	
CCE		119			
Celebrity	046				
Centurion	114,175				
Century			075		
CGE		038			
Changhong	018				
Channel Master			096		
Chaparral	210				
Chun Yun	005,014,029,041 076,089,100,113 121,202,204,214 242				
Chung Hsin	005,014,020,024 073,081,121,190 204	049			
Cimline		119			

**Device Code List For VT3630B**

**A U X**

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD
Clairtone	048				
Color Tac	267				
Colortyme	113,149,176	025,109			
Colour Voice			005		
Colt		119			
Concerto	113,176				
Contec/Cony	048,107,148,157 173,177,192,201		034		
Coronado	178,179				
COX	265				
Craig	148,177	047,070,103,119 141			
Crown	177,178	119			
Curtis Mathes	037,051,063,065 113,114,129,140 171,175,176,178 180,195	025,051,072,094 109,111,120,121 137,141			
CXC	148,177				
Cybernex		103			
Dae Ryung			019		
Daewoo	086,100,103,113 114,118,153,167 174,176,177,178 188,190,194,214 217,235,251,252 262	020,105,106,138 139,150,152,153 154,155			133,149,172 177
Dansai		119			
Daytron	100,103,113,114 175,176,178,188	105			
DBS			169		
DBX		025,109,113,142			
Decca		038,045			
De Graaf		064			
Denon				001	175
Diamond			043,133		
Disco Vision				115	
Dish Network			190,196,197 198,200,201 272		
Distar	061			115	
Drake			082,083,084 096,126,127 147,160,161		
DSS			168		
Dual		113			
Dumont	100,236	103,150			
Dynamic Bass				039	
Dynatech		038,066,097,107 109,120			

**Device Code List For VT3630B**

**A U X**

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD
Eagle			009,019,030 042,046,141		
Eastern			041,059,060 061,062,070 156		
Echosphere			198		
EchoStar			092,097,099 100,101,102 103,190,196 197,198,201 212		
Electroband	046,048				
Electrohome	044,046,048,068 100,113,176,178 188,190,195	047,049,100,103			
Electrohonic		047			
Elta				148,154	
Emarex		060			
Emerson	048,054,084,097 098,100,112,113 133,134,135,136 137,138,139,141 136,148,157,158 169,176,177,178 179,188,195,206 209,234	035,038,046,047 049,052,055,056 072,079,098,099 100,101,102,107 110,111,112,116 120,130,131,132 133,134,135,136 140,150		038	155
Envision	113,114,176				
Ether	089,100,202				
EUROSTAR			150		
Everquest			016		
Expressvu			190,196,198		
Ferguson		113			
Fidelity		038			
Finlandia		019,045			
Finlux	136	019,038,045,064 107			
Firstline		049,119,150			
Fisher	117,168,195	019,020,047,070 088,092,093,117		029	156
FORTEC STAR			186,187		
Fuji		060,072,083,084			
Funai/ Fullness	011,029,030,039 040,042,136,148 177	038,039,040,103 107,119,120			
Funtach			170,171		
Futuretech	177				
GAB		119			

**Device Code List For VT3630B**

**A U X**

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD
Garrard			038		
G.E.	051,054,061,065 068,083,100,108 113,131,141,143 145,146,176,180 184,187,222,235	051,072,085,086 094,098,103,137 141	195		171
GEC		045			
Gemini			016,131,132 134,135		
General (Fujitsu)	033,136	043	017,023,093 120,130		
G.I./Jerrold			001,003,011 012,013,014 016,017,023 050,093,125 128,129,130 135,140,163 180		
Gibraltar	100,114				
Gintai	205				
GMI			052,071,073 142,155		
Golden			030		
Goldstar	096,100,113,157 171,175,176,178 179,184,188,190 191,223,248,264	025,046,047,091 109	030	015	
Goodmans	136	037,038,047,119			
Go Video		103			157
Gradiente		038			
Graetz		113			
Granada	164	066,072			
Grandin	054,177	038,047,119			
Grundig		045		069	
Grunpy	136,177				
Haitai				105	
Hallmark	100,113,136,176				
Hamlin			010,019,020 123,133		
Harley Davidson		038			
Harman Kardon		025,109			161,196
Harvard	100,136,177	119			
Harwood		119			
Hawaii				117	
HCM	054				
Head Quarter		020			
Hinari	136	103,119			

**Device Code List For VT3630B**

**A U X**

**Device Code List For VT3630B**

**A U X**

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD
--------------	----	------------	------------	-----------	-----

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD
--------------	----	------------	------------	-----------	-----

Hi-Q		070			
Hisawa	054				
Hitachi	004,014,019,034 069,086,095,099 100,107,113,157 162,164,173,176 178,179,184,188 201,203,204,207 214,224,225,238 255	011,038,064,065 069,095,107,113 120	023,032,119 121,206,208	017,038,115	168
Hughes			199,202,204 208,209,273 274		
Hwalin			124,164		
Hypson	054				
Hyundai				118	
IEEC			009,058,065 066,141		
Ima	177				
IMC			173		
Imperial		038			
Infinity	037,082,167				
Inkei				007	
Instant Replay		067,072			
Integra				180	
Interfunk		045			
ITT		019,020,103,113			
Janeil	160				
Jasco			048,069		
JBL	037082,160,167			078,079	
JCB	046				
JCL		072			
JC. Penney	047,050,051,065 100,101,113,114 131,141,145,171 175,176,178,180 184,187,190,201 202	006,025,047,064 067,072,088,095 103,109,127,128 137,141,142			
Jean	014,057,089,100 202,204,205,214				
JEBSEE			047,068		
Jensen	113,176	062,113			
JVC	022,023,024,067 075,081,093,107 129,157,165,166 187,201,261	016,017,018,020 025,030,046,062 087,088,096,109 113,127,139,142 151	200,272	008,027031	129,164
Kaisui	054	119			

Kale vision			134		
Kawasho	113,176				
KEC	171,177	047			
Kenwood	100,113,114,176	020,025,030,062 088,096,109,113 127,139,142		018,019,028 051,059,060	130
KLH		119			
Kloss Novabeam	060,109,114,160				
KMC	178,179,188				
Kodak		047,072			
KOKA			055,057,118 144		
Kolin	005,014,020,024 041,073,081,121 190,204,269				
KONKA	243				169,174,179 183
Krell				069	
KTV	048,113,114,128 177,178,179,188 209				
Kyocera				046	
Legend				099	
LEON			052		
L/G	100,114,156,179 223,259,248	046	052		193
Lloyd		038,107,109,116 119,120			
Lloytron	178				
Loewe	082				
Lodgenet	063				
Logik	063,177	119			
Luxman	113,176			032	
Luxor		019,020,037,049			
LXI	037,057,065,082 100,101,175,195 206	038,046,047			
Macom			081,096,119 120		
Magnavox	037,060,082,100 109,113,114,127 131,132,162,163 167,175,176,178 179	045,047,072,075 123,137,144	004,005,006 007,008,037 038,039,042 046,203,207 275	022,056,059 069	
Magnin		103			
Majestic	063,236				
Marantz	037,060,082,109 113,114,125,176 190	025,045,072,088 109,127,129,142 144		003,040,069	

**Device Code List For VT3630B**

**A U X**

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD	
Marta		025,046,047				
Matsui	098,178	055116		069		
Matsushita		045,072				
MCS				003		
Megatron	100,164,202					
MEI	048	072				
Memorex	063,100,195	019,020,038,046 047,066,070,072 103,107,108,120	024			
Metz		006				
MGA/Mitsubishi	005,020,021,044 090,097,100,113 114,117,136,141 175,176,188,190 206,226,227,263 269	014,015,029,030 049,062,063,064 087,089,090,096 100	158	025	131	
MGN Technology		103				
Micro Formula			107			
Midland	065,178,187,236	085				
Mina			157			
Minolta		064,095				
Mission				069		
Motorola	037,083,187,206	066,072				
Montgomery Ward		066,097				
Movie Time			016			
Minutz	131,184					
MTC	048,100,113,114 171,176,190	038,103,107,120 141				
MultiTech	136,177	038,085,107,119 120,141				
Multivision	124					
Mustek					176	
Myland				119,120		
NAD	057,092,100,101				184	
Nakamichi					181	
NEC	031,032,041,061 068,079,080,100 113,114,160,175 176,187,190	019,020,025,026 030,041,042,046 062,088,096,109 113,121,126,127 129,139,142		033		
Nesco	136					
Newave	069,106,205,206	046				
Nikko	100,103,114	047				
Noblex		103				
Nokia		019,020,103	188			

**Device Code List For VT3630B**

**A U X**

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD	
Novavision			019,040,089			
Nordmende		113				
NSC			036,134			
NSM				069		
NTC	103					
OAK			033,034,139			
Olympus		072				
Omega			016			
Onking	209					
Onkyo				010,011012, 013	180	
Onwa	177					
Optimus	092,195,207	019,047,066		019,039,041 042,043	125,168	
Optonica	206,207	037				
ORBIT			095			
Orion	136,177,234	035,055,110,112 116				
Oritron					152	
PACE 500			183			
PACE 5000			184			
PACIFIC			178			
Panasonic (National)	010,015,016,017 028,037,050,058 068,070,082,083 088,089,094,108 122,130,145,159 161,167,187,247 254,268	006,007,008,012 027,028,031,050 067,072,112,118 137	003,019,024 114,148,175 193,194	003,020,061 062,112,122	121,173	
Panda				108		
Pansat			094			
Paragon (Zenith)			021,024,117			
PATHER			009			
PBI	107					
Pentax		064,095				
Philco	037,060,068,082 100,109,113,114 127,132,154,157 162,163,167,176 178,179,190	045,072,075,123 137				
Philips	036,037,056,060 068,082,100,109 113,114,122,132 154,156,157,162 163,167,176,179 198,215,216,256	037,045,067,072 144,145,146	004,005,006 007,008,037 038,039,042 046,122,152 203,207,275	068(Tuner) 070(REC) 071(VCD) 067(AMP) 022,052,066 069	071	
Philips Magnavox			203,207			
Pilco		072				

**Device Code List For VT3630B**

**A U X**

**Device Code List For VT3630B**

**A U X**

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD
--------------	----	------------	------------	-----------	-----

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD
--------------	----	------------	------------	-----------	-----

Pilot	114,171,178	047			
Pioneer	074,092,100,108 113,123,176,187 228	030,044,062,064 074,091,123,139 142	002,022,115 116	004,020,059 064,065,098 115,140	125,168
Polestar	103				
Popular Mechanic			068		
Portland	100,103,113,176 178,179,188,190	105,138,139			
Praxis	211				
Premier			035		
Priceclub	171				
Primestar			093		
Proline		038			
Prosat			088		
Proscan			195		
Protec		119			
Proton	014,041,076,100 104,113,126,157 176,178,188,196 202,204,205,214	006,067		069	
Prism	083,187				
Pulsar	100,103,236	047,103	024,030		
Pulser	100,103,236				
QED				069	
Quarter		020			
Quartz		020,088			
Quasar	050,068,083,108 146,187	006,072,137		003,020	
RAMPAGE			174		
Randex		047			
Radio Shack	051,065,087,107 114,148,157,175 177,178,195,207	037,038,047,066 070,072,088,093 097,100,103,107 120		023	178,185
Radix		047			
Randtek			042,046		
RCA	047,051,065,066 068,100,105,113 143,152,176,180 190,206,213,222 229,230	051,064,066,067 069,071,072,086 094,095,103,118 120,124,141,148 149	044,086,114 168,182,195 210	029,038,058	127,132,171 178,185
RC-AK			095		
Realistic	100,107,114,169 175,177,178,195 207	019,020,037,038 046,047,066,070 072,088,093,097 100,103,107,120 137	110	038,039,040 041	
Regai			019,020,123 133		

Regency			037,041,123		
Rembrandt			017,134		
Rhapsody	048				
Ricoh		072,083			
ROTEL				047,048	
Runco	114,171,236	047	024		
SABA		113			
SAE				069	
Saisho	098	101			
Salora		089			
Sampo	024,041,042,052 073,086,100,106 113,114,142,175 176,178,205,206 214,248,260	023,066,097			160 086
Samsung	070,100,107,113 114,140,144,157 167,170,171,175 176,178,179,188 189,190,197,200 214,237,240,249 250,264,270	059,085,086,103 104,111,115,133 141,150	004,022,030 098,134	110,113	128
Samsux	178				
Sanky		066			
Sansui		062,113,119,122 142		021,035,069 137	
Sanyo	014,024,025,026 027,034,035,040 041,049,051,110 117,120,168,173 175,186,195,204 214,218,231,232 241	019,020,021,022 068,070,088,103		022,036,039 055	084
Schaub Lorenz		113			
Scientific Atlanta			013,019,040 089,112,113 172		
Scimitsu	100				
Scotch	100				
Scott	100,114,136,137 148,157,175,177 178	049,063,079,089 101,110,112,132 134,150			
Sears	030,037,051,057 065,067,100,101 110,111,113,117 136,168,171,175 176,178,179,195 201,235	019,020,046,047 064,070,072,088 092,093,095,117			

Device Code List For VT3630B

A U X

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD	
Seg					165	
Sega				115		
SEI		045				
SET	098					
Sharp	009,038,043,059 087,106,113,133 157,173,176,178 179,188,192,206 207,208	024,037,058,066 097,100,138	137	019,040,111	159	
Sherwood				007,023,040 053,054	153	
Shinco				107	171	
Shintom		038,064,083,084 103,119				
Shogun	100	103				
Sigma			034			
Signal			016,030			
Signature	037, 063,065,100		017,023			
Simpson	060,114,132					
Singer	187	047,103,119				
Sinudyne	098					
Sky Giant			063,075,138 153			
Skardin			218,220			
Skymaster			215,216,217 219		192	
SL Marx			030			
Sony	000,001,012,013 014,024,045,046 061,073,097,181 198,202,204,214 232,244,245,246	000,001,002,003 004,005,060,072 081,082,083,084	169,191	000,037,049 063,114,136	124,167 145(PS2)	
Soundesign	100,113,132,136 176,177					
Sowa	005,014,024,057 068,072,073,172 199,200,204,214					
Space TV			035			
Spectricon	100,114,177,202					
Sprucer			114,148			
Squareview	030					
SSS	100,113,177					
Standard component			134			
Starcom			016,023,130			
Stargate			016,030			
Starlite	100,177					

Device Code List For VT3630B

A U X

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD	Airconditioner
Starquest				016		
Star Sight				209		
STS		064		080		
Sun Moon Star 2400				181		
Supra	178					
Supre-Macy	132,160,178					
Supreme	046					
Sylvania (A? )	037,060,082,085 100,109,113,114 127,131,132,162 163,167,175,176	045,049,067,072 075,089,120,123 137	031,032	022,069		
Symphonic	030,136,137,148 177	038,107,120				
Synco (E )	014,024,073,198 202,204,206,214					
TADA (!" )				053,162		
TADIRAN				030		
Taicom				055		
Tai Wah	064,212					
Tandy	065,178,206,207	088,120				
Tashiko(2 # \$ )	205	046				
Tatung (2 % )	005,010,014,020 024,037,041,057 068,072,073,083 101,172,187,199 200,202,204,214	013,038,062,113 127			134	083
Tay Shoen				058,154		
Teac (&' )		038,107,113,120 127		002,006014, 030040	168	
Technics	050,083,108,187	006,072		003,030		
TECHNOSAT				149		
TECHNOVISION	151					
Techwood	050,083,113,176 187,202					
Teco ()* )	002,014,028,029 061,077,078,079 086,091,183,187 204				194	087,095
Tedelex				104		
Teknika	037,055,063,100 103,113,132,136 157,160,167,171 176,177,178,179 188,190,201	038,043,046,047 072,080,107,120	025			
Telecaption II	136,147,178					
Telefunken (\$ +,- )		113				
Teletent	063,178					

**Device Code List For VT3630B**

**A U X**

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD
Teleview			030		
Tera	014,076,100,113 176,204,205,214				
Texscan			029,031,032		
Theta Digital		114			168
Thomson/ ProScan	051,065,180	051,113			126
Thorn		113			
TMK	098,101,113,176	098,103,111,116			
Tocom			000,001,008 111		
Tomashi	054				
Toshiba	003,010,018,020 024,041,057,101 102,147,150,168 171,172,195,199 200,201,207,214 256	009,010,013,048 049,061,064,089 093,113,117,134 150	024,074,078 081,105,189 192,205,269 270	024,026,059	123,158,163 091
Tosonic	048				
Totevision	178	046,047,103,141	112		
Trans PX			048,069,072 075,112,117 136,179		
Tri-vision			011,109,125 137		
Tri-Lex	071 (MPEG Card)				
Triumph	098	116			
Tuntex	100				
Tusa			016		
TV 86			030		
U-MEN	187				
Uniden			079,209		
Unika			004,006,028		
Unitech		103,141			
United cable			130		
United satellite			077,079		
Universal	065,131,184		026,027		
UPMOST	155 (MPEG Card)				
Veccom			107		
Vector Research	114	025,063,089,109 142			
Victor	067,081,165	063,142,150			
Videocon	003,018				
Video Concepts		025,100,109,142 150			

**Device Code List For VT3630B**

**A U X**

Brand/Device	TV	BATH / VCR	Cable/Sat.	CD/LD/VCD	DVD
Videosonic		038,103,119,141			
Videotronic		072			
Videoway			024,108		
Vidikron	037				
Vidtech	100,113,190				
Viewstar			004,005,006 007,008,037 038,039,042 046		
Viking	160				
Visa	115				
Vortec			098		
Walmart			068		
Warner Amex			022		
Wards	037,051,060,063 082,087,100,109 113,114,116,131 132,136,137,162 163,175,176,178 184,190,207	037,038,046,064 066,070,072,094 097,100,103,107 119,120,125,141			
Warton	081				
Webvideo			213		
Wharfedale					182
Whirlpool	196				
Winer			054,087,090		
WISO			026,056,145		
XR-1000		038,072,103,119			
Yamaha	100,113,114,176 190	025,088,109,113 127,142		005,009034	166,170
Yorx	114,175				
Zenith	062,063,103,219 233,236	047,062,083,084	021,024,076 082,083,084 106,117,126 147	057,080	151,155,162
Zentek			068		
Zonda	202				